



Setup up for your iKeyboard 4S(PDIII) controller section



Hardware Controller Setup

- System Options
 - Audio System
 - Audio Devices
 - MIDI
 - Hardware Controller**
 - Metronome
 - Record
 - Playback
 - Performance
 - Extended Buffer Settings
- Program
 - General
 - Undo
 - Object Lock Definitions
- Keyboard, Menu & Mouse
 - Keyboard / Menu
 - MIDI Editor
 - Special Keys
 - Mouse
 - Mousewheel
- Design
 - Skins
 - View Options
 - Colors
- Effects
 - Option Administration
 - Project Options

Controller Setup Customize Controller Options Fader Scaling

- Mackie Control

Add New
Remove
Save Setup As..

EUCON
 Activate EUCON

7

9

8

Controller Setup Customize Controller Options Fader Scaling

- Mackie Control

Add New
Remove
Save Setup As..

MIDI In: MIDIIN2 (iKeyboard 4S(PDIII)V)

MIDI Out: MIDIOUT2 (iKeyboard 4S(PDII))

Track count: 8

Output: Send Echo

Internal mode: Mackie_Set

Apply **OK** Cancel

10

11

12

Setup for your iKeyboard 4S(PDIII) Keyswitch instrument input section

